


Assignment #3. LFP, ECoG, & EEG Data Analysis

- The report needs to be submitted in an electronic format (word document, pdf, etc.) via email (zenas.c.chao@gmail.com)
- Put your name in the filename.
- You need to submit your report before Dec 13. Late assignment will not be accepted.
- You are encouraged to discuss with your classmates, but you need to write the report yourself. Plagiarism will be severely punished!
- You need to attach your codes in the report. Remember to use "%" to comment your programs.
- Use function "saveas" to create figures.

EXERCISE 3.1

Download the ECoG data ("ECoG_data.mat" from the class website). The dataset was recorded from 32 channels in a monkey during a reaching-and-grasping task. The data contains three variables:

- **ECoG:** data points X channels
- **times:** timings (in second) of the data points
- **Movement_onset:** The reaching onsets (in second). There are 133 trials




- 1) What is the sampling rate of the data (in Hz)?
- 2) Plot the averaged ERP from channel 18. Include signals from 2 seconds before the movement onset to 2 second after the movement onset. HINT: use the trick from Part 5.
- 3) Plot the averaged TFR from channel 18. Include 2 seconds before the movement onset to 2 second after the movement onset. Use the code in Part 11 with the following parameters:

```
params.Fs=          ; %Sampling rate in Hz (from question (1))
params.tapers=[2 3]; %Taper parameters
params.fpass=[5 120]; %Look at 5-120 Hz band
movingwin=[0.3 0.03]; %Window to compute spectrum
```

- 4) Based on the TFR plot, what happens to the low frequency power (<20Hz) around the movement onset? Write down your observations.


EXERCISE 3.2 (continued from exercise Part 7)

From exercise Part 7, ERPs from different movement directions are shown below:



- 1) Design a measurement (for example, the minimum ERP value between 0 and 500ms), and show how this measurement changes according to the movement direction. To answer this, you need to plot the tuning curve: the measured value (y-axis) vs. movement directions (x-axis).
- 2) Plot the measure values vs. the movement angles (see example below). HINT: use the "polar" function.


Variable "direction"	1	2	3	4	5	6	7	8
Movement angle	0	45	90	135	180	225	270	315



3) Do you see “direction tuning” in your measurement? Describe your finding.

[BONUS] EXERCISE 3.3 (continued from exercise Part 11)

From exercise Part 11, TFRs from different movement directions are shown below:



- 1) Design a measurement (e.g. the average power between 0 and 500ms and between 10 & 20Hz), and show how this measurement changes according to the movement direction by plotting the tuning curve (as in EXERCISE 3.2).
- 2) Plot the measure values vs. the movement angles (as in EXERCISE 3.2).
- 3) Do you see "direction tuning" in your measurement? Describe your finding.